Quick Start Guide






PHILIPS

What's in the Box?


You should find these items upon opening the box.



Connection

1 Connect the speaker wires to the **SPEAKERS** terminals.

2 Connect the power cord of the system to the AC power outlet.




Tip:

It is unnecessary to connect the FM pigtail antenna since it is fixed to the main unit.




Setting the clock

1 In standby mode, press and hold **CLOCK/DISPLAY** on the remote control set for 2 seconds.



7 Press **CLOCK/DISPLAY** to confirm the time.

Step C Enjoy



Step C Enjoy

Programming and tuning to radio stations

- 1 Select TUNER source.
- **2** Press **PROG** on the remote control for more than two seconds to program all available stations in order of waveband.
- 3 Press ALBUM/PRESET +/- until the desired preset station is displayed

Tip:

Detailed playback features and additional functions are described in the accompanied owner's manual. Notes for the remote control: - First, select the source you wish to control by pressing one of the source select keys on the remote control (DISC or AUX, for example).

- Then select the desired function (\triangleright II, $|\triangleleft, \triangleright|$ for example).



2007 © Koninklijie Philips Electronics N.V. All rights reserved. http://www.philips.com

