

Always there to help you

Register your product and get support at
www.philips.com/welcome



HTD3500K



Quick start guide

PHILIPS







EN Before using your product, read all accompanying safety information

MS Sebelum menggunakan produk anda, baca semua maklumat keselamatan yang disertakan

ZH 使用产品前，请阅读所有随附
CN 的安全信息


ZH 使用您的產品前，請先閱讀所有附隨的安全資訊
TW



Power cord



HDMI




1



EN Connect the home theater

MS Sambungkan teater rumah

ZH 连接家庭影院
CN

ZH 連線至家庭劇院
TW





2


EN Switch on the home theater

MS Hidupkan teater rumah


ZH 打开家庭影院
CN

ZH 開啟家庭劇院
TW

1



2



3

EN Complete the first time setup








MS Lengkapkan persediaan kali pertama

ZH 完成首次设置

CN






ZH 完成首次設定



TW



4

EN Use your home theater
MS Gunakan teater rumah anda
ZH 使用家庭影院
CN
ZH 使用您的家庭劇院
TW





Specifications are subject to change without notice
 © 2012 Koninklijke Philips Electronics N.V.
 All rights reserved.

HTB3500K_98_QSG_V1.0

