

Philips
Micro Hi-Fi System

CD, FM
4 W

MC127

# Relax with great music

### Obsessed with sound

Tune in to superb sound from a surprisingly compact and sleek design. The MC127 Micro Hi-Fi System will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

### **Enrich your sound experience**

- Dynamic Bass Boost for deep and dramatic sound
- Play CD, CD-R and CD-RW discs
- MP3 Link for portable music playback

#### Easy to use

• Digital tuning with 20 pre-set stations for extra convenience

### Fits any space, any lifestyle

- Compact design
- Easy-to-use remote control included



## Specifications

- Output Power: 2 x 2 W RMS/2 x 4 W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

#### Loudspeakers

• Main Speaker: 3" woofer

#### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme
- · Loader Type: Top

### Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Station presets: 20

### **Connectivity**

- · Other connections: FM fixed pigtail antenna
- · Audio Connections: 3.5 mm Line in

· Loader type: top

#### **Accessories**

- Included accessories: IFU/User Manual, World Wide Warranty leaflet, MP3 Line-in cable
- Remote control: 15-key remote control

- Main speaker dimensions (W x H x D):
- Packaging dimensions (W x H x D): 480 x 220 x 238 mm
- Weight incl. Packaging: 3.8 kg

#### Convenience

- Set dimensions (W x H x D): 152 x 175 x 250 mm
- 132 x 175 x 158 mm









Issue date 2014-07-22

Version: 2.1.8

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 79891 EAN: 87 12581 61305 1

www.philips.com

## Highlights

### **Dynamic Bass Boost**

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.