

Philips CD Soundmachine

Power design

AZ1839

# Great portable sound

Want to enjoy the music collections stored at portable music player without using headphone? Plug the USB Direct socket to the Philips CD soundmachine and enjoy your favorite digital music through the powerful speakers - anytime, anywhere.

## Powerful sound you can hear and feel

- Bass Reflex Speakers for a deep, powerful sound
- 10.2 cm (4") full range speakers for powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- 2x1W RMS total output power

## Multisource music enjoyment

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM/MW tuner for radio enjoyment

## Easy to use

- MP3 Link for portable music playback
- Stereo headphone socket



# Specifications

#### **Audio playback**

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/ previous track search, repeat/shuffle/program

## Connectivity

- USB: USB host
- Audio/Video output: Headphone (3.5mm)
  MP3 Link: 3.5mm stereo line in

# Tuner/Reception/Transmission

- Antenna: FM antenna
- Tuner bands: FM, MW

#### Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

#### Loudspeakers

- No. of built-in speakers: 2
  Loudspeaker enhancement: bass reflex speaker system
- Speaker grille finishing: metal







• Display type: LCD display

#### Accessories

- Cables/Connection: \*Flat pin adaptor, 3.5 mm stereo line in cable, power cord
- User Manual: B-Portuguese, Spanish
- Warranty: Warranty Certificate

### Dimensions

- Gross weight: 3.8 kg
- Packaging width: 457 mm
- Packaging height: 283 mm
- Packaging depth: 210 mm
- Weight: 2.8 kg
- Main unit depth: 240 mm
- Main unit height: 168 mm
  Main unit width: 420 mm

#### Power

- Battery type: D size (LR20)
- Battery voltage: 1.5 V
- Power supply: 110 127V and 220 240V AC
- voltage selectable • Number of batteries: 6



# AZ1839/55

# Highlights

### **USB Direct**

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

### **Bass Reflex Speakers**

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

## MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

