Quick Start Guide



Step A Connect

Step B Setup


Step C Enjoy

What's in the Box?

You should find these items upon opening the box.





rable stand



Studs (x2) used to attach speakers to main unit



















Tips

- See the User Manual for how to mount the main unit and speakers onto wall.
- See "Connect AV devices" for more AV connection options.
- For connection and operation of your AV devices, see the respective user manuals.

- Attach speakers to the main unit.
 - 2

Slide the table stand onto the bottom of the main unit.




Place the main unit and speakers.





Connect AV devices




Connect power.









Step B Setup

Set clock

IMPORTANT!

- To set clock in the Eco Power Standby mode, first press and hold \circlearrowleft for more than 2 seconds to switch to the standby mode.

1

In the standby mode, press and hold **CLOCK** to enter the clock setting mode.

- → Clock is displayed and the hour digits begin to blink.
- 2

Press + VOL - to set the hour.

3

Press CLOCK to confirm.

- → The minute digits begin to blink.
- 4

Press + VOL - to set the minute.

5

Press CLOCK to confirm the clock setting.

Step C Enjoy

Play from USB

1

Flip open the cover on the front panel.

2

Insert the USB plug of a USB device into the •socket

3

Press USB to select the USB source.

- The total number of tracks is displayed.
- 4

Press ALB/PRESET/▲▼ to select a folder.

5

Press <a> / ▶ to select a file.

6

Press II to start play.



Play connected AV devices



Press AV, HDMI, or COAX/OPT to select an AV source.

Tip

Detailed playback features and additional functions are described in the accompany owner's manual.



© Royal Philips Consumer Lifestyle N.V. 2008 All rights reserved.

http://www.philips.com

