


Philips Mini Speaker

Party extender

Use with Philips party machine Dynamic light 240 W



FWP1000



Extend your party-machine music

An extra speaker for wider reach

Party on with the Philips Mini speaker. The 240 W speaker adds life to parties, bringing music to any part of your home. It works with all Philips party machines, and is designed for flexible placement and to be easy to set up.

Extend your party-machine music

- 240 W RMS total output power
- Flexible placement around the house
- Simple setup with any Philips party machines
- Dynamic lighting for dancing to the beat



Specifications

Sound

• Total Sound Power (RMS): 240 W

Loudspeakers

- Speaker drivers: 2" tweeter, 5.25" woofer
- · Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Accessories

- User Manual: Spanish, B-Portuguese
 Cables/Connection: *Flat pin adapter, power cord
- Others: Quick start guide
- · Warranty: Worldwide Guarantee booklet

Dimensions

- Gross weight: 15 kg
- Packaging height: 400 mm
- Packaging width: 780 mm
- Packaging depth: 430 mm
 Product dimensions (WxDxH): 704 x 364 x 324 mm

Power

• Power supply: 100 - 240 V AC, 50/60 Hz



Highlights

Dynamic lighting



Step in time to the dazzling beat of music. Cool lights blink to the rhythm of songs, adding fun and excitement to tunes. When you don't want the lights on, you can simply turn the feature off. Add glam and spice to dance parties, sizzling celebrations and cool events with these sensational dynamic lights.



Issue date 2014-07-18

© 2014 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 1.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V.

12 NC: 8670 000 85928 EAN: 87 12581 62975 5 or their respective owners.