

Philips
CD Soundmachine with
Dynamic Bass Boost

CD
cassette

AZ127



Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ127 lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

The ultimate listening experience

- Play CD, CD-R and CD-RW discs
- Autostop cassette deck
- FM tuner for radio enjoyment

Easy to use

- 20-track CD programmable
- $\bullet \ \mathsf{CD} \ \mathsf{Shuffle/Repeat} \ \mathsf{for} \ \mathsf{personalized} \ \mathsf{music} \ \mathsf{enjoyment} \\$
- · Audio-in for easy portable music playback

Rich and clear sound

• Dynamic Bass Boost for deep and dramatic sound



Highlights

Autostop cassette deck



Autostop cassette deck

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical

Tuner/Reception/Transmission

- Tuner Bands: FM
- Antenna: FM Antenna

Sound

- Output power (RMS): 2 X 1W
- Sound Enhancement: Dynamic Bass Boost
- · Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Loudspeakers

• Built-in speakers: 2

Convenience

Display Type: LCD

Connectivity

• 3.5mm stereo line in: (AUDIO IN)

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Number of batteries: 6
- Mains power: 220V 240V

Accessories

- Quick start guide
- Warranty: Warranty leaflet

Dimensions

- Packaging dimensions (W x H x D): 326 x 275 x 158 mm
- Product dimensions (W \times H \times D): $300 \times 240 \times 133$ mm
- Weight: 2 kg
- Weight incl. Packaging: 2.4 kg



Issue date 2022-05-12

Version: 2.0.9

© 2022 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 95191 EAN: 08 71258 16601 92

www.philips.com