







Registre seu produto e obtenha suporte em
www.philips.com/welcome

HTS3560




Quick Start


PHILIPS




FM Antenna




Power cord



Video cord




HDMI cord




PHILIPS


1






2



3





2

1

SOURCE

TV

AV

2

3

4

HOME THEATER

5

6

HOME THEATER

7

8



HOME THEATER

Video Setup	Menu Language	English
Audio Setup	Audio	•
Network Setup	Subtitle	•
EasyLink Setup	Disc Menu	•
Preference Setup	Parental Control	•
Advanced Setup	Screen Saver	•
	Auto Subtitle Shift	•
	Change Password	•



Menu Language	Auto
Audio	English
Subtitle	Espanol
Disc Menu	Portugués
Parental Control	
Screen Saver	
Auto Subtitle Shift	
Change Password	




3

DISC



FM





Evite o uso prolongado do aparelho com volume superior a 85 decibéis, pois isto poderá prejudicar a sua audição.
Potência total de saída de 800W RMS (10% THD)



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2011 © Koninklijke Philips Electronics N.V. All rights reserved.
sgsna_1103/X_78_v1

Be responsible
Respect copyrights

