

Always there to help you

Register your product and get support at
www.philips.com/support



NC1



User manual

PHILIPS

Contents

1	Important safety instructions	2
	Hearing Safety	2
	General information	2

2	Your noise canceling on-ear headphones	3
	What's in the box	3
	Overview of your noise canceling headphones	4

3	Get started	5
	Charge your headphones	5

4	Use your headset	6
	Activate/Deactivate noise cancelation	6
	Connect to airline audio systems	6

5	Technical data	7
----------	-----------------------	----------

6	Notice	8
	Declaration of conformity	
	Disposal of your old product and battery	8

1 Important safety instructions

Hearing Safety



Danger

- To avoid hearing damage, limit the time you use headphones at high volume and set the volume to a safe level. The louder the volume, the shorter the safe listening time is.

Be sure to observe the following guidelines when using your headset.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume continuously upwards as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Excessive sound pressure from earphones and headphones can cause hearing loss.
- Using headphones with both ears covered while driving is not recommended and may be illegal in some areas while driving.
- For your safety, avoid distractions from music or phone calls while in traffic or other potentially dangerous environments.

General information

To avoid damage or malfunction:



Caution

- Do not expose headphones to excessive heat.
- Do not drop your headphones.
- Headphones shall not be exposed to dripping or splashing.
- Do not allow your headphones to be submerged in water.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives.
- If cleaning is required use a soft cloth, if necessary dampened with a minimum amount of water or diluted mild soap, to clean the product.
- The integrated battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Use only the Philips airline adapter to connect the headphones to airplane seat jacks. Do not use other airline adapters as they might not result in correct response or even result in personal injury such as burns or property damage due to overheating. Remove the adapter and disconnect immediately if you experience warming or loss of audio.
- Do not insert any plug into the power jack of the airplane seat because it may damage the headphones and result in personal injury.
- Never use your headphones when you are operating a motor vehicle, riding a bicycle, running or walking in traffic areas. It is dangerous and illegal in many places.

About operating and storage temperatures and humidity

- Operate or store in a place where temperature is between -15°C (5°F) and 55°C (131°F) (up to 90% relative humidity).
- Battery life may be shorter in high or low temperature conditions.


2 Your noise canceling on-ear headphones

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.


What's in the box




Philips noise canceling on-ear headphones NC1




Audio cable with microphone and in-line control for handsfree calling



Airline adapter



USB charging cable (for charging only)




Travel case



Quick start guide

Overview of your noise canceling headphones



- ① Feedforward microphone
- ② 3.5mm audio input jack
- ③ Active noise canceling (ANC) on/off button
- ④ Microphone and in-line control for handsfree calling
- ⑤ Micro USB charging port
- ⑥ Charging indicator
- ⑦ ANC power indicator
- ⑧ Feedback microphone

3 Get started

Charge your headphones



Note

- Before you use your headphones for the first time, charge the battery for 5 hours for optimum battery capacity and lifetime.
- Use only the original USB charging cable to avoid any damage.
- You can operate the headphones normally during charging.
- Normally, a full charge takes 2 hours.
- When the battery level is low, the white LED will flash.

Connect the supplied USB charging cable to:

- the micro USB charging port on the headphones and;
 - the charger/USB port of a computer.
- ↳ LED turns orange during charging and turns off when the headset is fully charged.
- ↳ LED turns white when ANC is on.


4 Use your headset

Activate/Deactivate noise cancellation

- Switch on the ANC on/off button to activate noise cancellation.
- Switch off the ANC on/off button to deactivate noise cancellation.
- When the battery level is empty or when the ANC function is not required, switch off the ANC on/off button to continue your call or listening to music.

Connect to airline audio systems

- 1 Connect the audio cable into the airline adapter:




- 2 Insert the adapter into the dual output jacks in the airplane seat.
 - One 3.5mm jack
Use the single plug. No adapter is needed.



- Two 3.5 jacks
Use the 3.5mm dual plug airline adapter:



- One power jack and two 3.5mm jacks
Use the 3.5mm dual plug airline adapter.
Make sure you insert it into two 3.5 jacks.



5 Technical data

- Active noise cancelation: Hybrid (4 microphones)
- ANC play time: 30 hours
- Music and talk time: Unlimited
- Low battery warning: available



Note

- Specifications are subject to change without notice.

6 Notice

Declaration of conformity

Hereby, WOOX Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC (EMC). You can find the Declaration of Conformity on www.p4c.philips.com.

Disposal of your old product and battery



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.



This symbol means that the product contains a built-in rechargeable battery covered by European Directive 2013/56/EU which cannot be disposed of with normal household waste. We strongly advise you to take your product to an official collection point or a Philips service centre to have a professional remove the rechargeable battery.

Inform yourself about the local separate collection system for electrical and electronic products and rechargeable batteries. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old

products and rechargeable batteries helps prevent negative consequences for the environment and human health.


Remove the integrated battery



Note

- Make sure the headset is disconnected from the USB charging cable before removing the battery.

If there is no collection/recycling system for electronic products in your country, you can protect the environment by removing and recycling the battery before disposing of the headset.



Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



2014 © WOOX Innovations Limited. All rights reserved.

Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by WOOX Innovations Limited under license from Koninklijke Philips N.V.

UM_NC1_00_EN_V1.0
wk1440

