








Register your product and get support at
www.philips.com/welcome

HTS3220




Quick Start

PHILIPS



Power Cord








Composite





FM

1







2

1

TV

SOURCE

TV

AV

2

3

HOME THEATER

5

6

HOME THEATER

General Setup



Easylink Setup

- Disc Lock
- Display Dim
- OSD Language
- Screen Saver
- Sleep Timer
- DivX(R) VOD Code

General Setup



- Easylink Setup
- Disc Lock
- Display Dim
- Screen Saver
- Sleep Timer
- DivX(R) VOD Code
- Auto
- English
- 繁體中文
- Melayu
- 简体中文
- Русский
- Hindi

3








MP3



USB



iPod / iPhone



Specifications are subject to change without notice
 Trademarks are the property of Koninklijke Philips Electronics N.V.
 or their respective owners
 2010 © Koninklijke Philips Electronics N.V. All rights reserved.
 sgythy_1006/98_v1

Be responsible
 Respect copyrights

