






Register your product and get support at
www.philips.com/welcome

HTS5520
HTS5530




Quick Start

PHILIPS




Audio/Video




FM Antenna



1





2




3




4




5






6



2




1




2

3




HOME THEATER




4

5





HOME THEATER





3

DISC





FM








MP3



USB



www.philips.com/support



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgsn_1014/51-94-98_v2



Be responsible
Respect copyrights

