



Philips
Universal remote control

Big button

SRU4007



7 device remote with full back lighting

Back lighting and big buttons

7 device remote control with full led back lighting as well as oversized buttons. Perfect for use with cable and dss set top boxes with advanced dvr use.

Great convenience

- Learning copies favorite functions from original remotes
- Big buttons increase operability and readability
- Uses LED's to light up every button on the remote

Replace a table full of remotes

- Includes all the buttons to operate DVR, DVD and SAT
- The remote can capture codes from your old remote

PHILIPS

Specifications

Packaging dimensions

- UPC: 6 09585 15734 7
- Number of products included: 1
- Packaging type: Blister
- Packaging dimensions (W x H x D): 11.5 x 28 x 3.8 cm
- Nett weight: 0.125 kg
- Gross weight: 0.175 kg
- Tare weight: 0.05 kg

Outer Carton

- GTIN: 2 06 09585 15734 1
- Number of consumer packagings: 12

- Outer carton (L x W x H): 45.5 x 30 x 15.5 cm
- Nett weight: 1.5 kg
- Gross weight: 3.15 kg
- Tare weight: 1.65 kg

Inner Carton

- GTIN: 1 06 09585 15734 4
- Number of consumer packagings: 4
- Inner carton (L x W x H): 28.5 x 14.5 x 12 cm
- Nett weight: 0.5 kg
- Gross weight: 0.8 kg
- Tare weight: 0.3 kg

Highlights

Learning favorite keys

To have your 5 favorite functions of your original remote available you can copy the signal transmitted from the original remote. If these are your/or your kids favorite channels you can even lock the remote to see any of the other channels.

Big button

Big buttons are larger size buttons on a remote to help read the label better. Additionally, pressing the button becomes more convenient, as the size has increased by 2 mm compared to the standard button remote size.

Full DVD, DVR, and SAT

Match the correct buttons with your lost or replacement remote with advanced DVD keys such as angle, zoom, subtitle, open/close, repeat, and title. For SAT you need guide, info, select, OK, scroll keys, quit, and menu. For DVR, play, fast forward, stop, record, T Central, thumbs up/down, chapter scan, and repeat.

Light up every button

Can't see in the dark. Try pressing small buttons on a remote when you can't see the keys. Change that with back lighting that light up the keys so you can see the keys as if it were the middle of the day. Small LCD lights are attached to the circuit board, that light up the keys, when you press the light button

Learn from your old remote

After you buy your universal remote, it seems you are missing a few of the buttons you liked to use on your old original remote, which prevents you from consolidating. When you want to use your favorite button, you have to go back to the original remote. On learning remotes, you can take the code for your favorite button on your original remote, and learn it/move it to the universal in 3 easy steps.



Issue date 2014-03-14

Version: 1.1.4

12 NC: 8670 000 40991
UPC: 6 09585 15734 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com