

Register your product and get support at
www.philips.com/welcome

SPS6010A/17



User manual

PHILIPS

1 Important safety instructions

This manual contains important information about the Philips remote controlled outlets. Read it carefully before you start the installation and setup.



Warning

- Do not operate your remote controlled outlets near water.
- Do not operate your remote controlled outlets if liquid of any kind is spilled onto or inside the unit.
- Do not disassemble or repair.
- Do not expose your remote controlled outlets to direct sunlight or place it near wall heaters, space heaters, or enclosed space prone to temperature increase.
- The Philips remote controlled outlets require a properly grounded outlet for safety and to protect the connected equipment. If you are not sure whether your home's electrical wiring has proper grounding, consult a qualified electrician.



Caution

- Risk of electrical shock! Not for use outdoors or in other wet or damp areas, with aquariums, in hazardous environments requiring failsafe performance (such as nuclear facilities or aircraft), or for medical or life support equipment.

with the instruction manual, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Recycling



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

The packaging of this product is intended to be recycled. Contact your local authorities for information about how to recycle the packaging.

Notice for USA



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance

2 Your remote controlled outlets

Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Overview



- ① **Button A**
 - Turn on/off the outlet of Receiver A.
- ② **Button B**
 - Turn on/off the outlet of Receiver B.
- ③ **Button C**
 - Turn on/off the outlet of Receiver C.
- ④ **Button ALL ON**
 - Turn on all the outlets of all receivers.
- ⑤ **Button ALL OFF**
 - Turn off all the outlets of all receivers.
- ⑥ **Remote control**
- ⑦ **Receiver A**
- ⑧ **Receiver B**
- ⑨ **Receiver C**

3 Get started

Note

- To avoid any potential hazard, use the power source supplied by your local authorities.

There are three receivers and one remote control. You can control up to three receivers with the remote control.

- 1 Plug the receivers into a properly grounded outlet.
- 2 Plug your devices into the AC outlet of receivers.


Install/Replace remote control battery

Caution

- Risk of explosion! Keep the battery away from heat, sunshine or fire. Never discard the battery in fire.
- Risk of product damage! When the remote control is not used for long periods, remove the battery.

For first-time use:


Remove the protective tab to activate the remote control battery.



To replace remote control battery:

- 1 Open the battery compartment.

- 2 Insert one **A23** battery with correct polarity (+/-) as indicated.
- 3 Close the battery compartment.



Control your devices

The plugged devices can be turned on or off easily by the remote control. You can control each plugged device individually or control all the plugged devices at the same time.

Note

- The remote controlled range (open field) is up to 40 feet.
- The output rating of each receiver is 125V/13A.

- Press button **A** to turn on/off the outlet of Receiver **A**.
- Press button **B** to turn on/off the outlet of Receiver **B**.
- Press button **C** to turn on/off the outlet of Receiver **C**.
- Press button **ALL ON/ALL OFF** to turn on/off all the outlets of the three receivers at the same time.

Tip

- If you want to purchase more than one unit, make sure that they have two different frequencies (1 and 2) as indicated by stickers on the back side of packaging. You can also find the stickers in the battery compartment of remote control and on the surface close to mains plug of the receivers. The remote control of this unit operates on either Channel 1 or Channel 2 frequency.

4 One Year Limited Warranty (USA only)

Philips warrants that this product shall be free from defects in material, workmanship and assembly, under normal use, in accordance with the specifications and warnings, for a period of one year from the date of purchase. This warranty extends only to the original purchaser of the product, and are not transferable. To exercise your rights under this warranty, you must provide proof of purchase in the form of an original sales receipt that shows the product name and the date of purchase. For customer support or to obtain warranty service, please visit our website www.philips.com/support. THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES. Philips' liability is limited to repair or, at its sole option, replacement of the product. Incidental, special and consequential damages are disclaimed where permitted by law. This warranty gives you specific legal rights. You may also have other rights that vary from state to state.

For support, please visit www.philips.com/support

