

Philips
CD Soundmachine

AZ1830

# Playback your digital music via USB Direct

Want to enjoy the music collections stored at portable music player without using headphone? Plug the portable player to the AZ1830's USB Direct socket and enjoy your favorite digital music through the powerful speakers.

## The ultimate listening experience

- Enjoy MP3/WMA music directly from your portable USB drives
- 10 hours of MP3-CD or 20 hours of WMA-CD music
- FM/MW tuner for radio enjoyment

#### Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- Multi-functional LCD display
- · Handy remote control



#### AZ1830/12

## Specifications

#### **Audio Playback**

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

#### **Connectivity**

• USB: USB host

#### Tuner/Reception/Transmission

Antenna: FM AntennaTuner Bands: FM, MW

#### Sound

- Output power (RMS): 2X1.0W
- Sound Enhancement: Dynamic Bass Boost
- · Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

#### Loudspeakers

• Built-in speakers: 2

- · Finishing: Metal
- · Loudspeaker types: Loudspeakers

#### Convenience

- Display Digits: 3
- Display Type: LCD

#### **Accessories**

- Included accessories: AC Power Cord, User Manual, Warranty certificate
- · Remote control

#### **Dimensions**

- Product dimensions (W  $\times$  H  $\times$  D): 361  $\times$  152  $\times$  239 mm
- Packaging dimensions (W  $\times$  H  $\times$  D): 406  $\times$  200  $\times$  270 mm
- · Weight: 2.2 kg
- Weight incl. Packaging: 2.8 kg

#### Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6













Issue date 2014-02-05

Version: 5.1.11

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 101 02378 EAN: 87 10895 93836 5 **www.philips.com** 

#### or their respective ov

# Highlights

### **USB** Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

#### MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A singe CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.