

# PHILIPS

Lens cleaner

CD/DVD

2-brush system

SVC2330



## Cleans and protects your CD/DVD player

Regular cleaning of your CD/DVD player's lens ensures optimum performance of your equipment. It is important to keep the optical laser lens clean and dust free. This dry-brush system safely removes dust, debris and other contaminants.

### **Maintain original sound quality**

- Audio system check for correct setting

### **Maintain original sound and video quality**

- Safe dry brush cleaning system

### **Easy to use**

- Voice instructions in 14 languages

# Highlights


## Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

## Audio system check

The audio system check determines whether the speakers are properly adjusted.

## Voice instructions



The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.

# Specifications

## Storage Media

**Supported formats:** CD-Audio, CD-ROM, DVD-ROM

## Outer Carton

**EAN:** 87 12581 57360 7  
**Length:** 54.3 cm  
**Number of consumer packagings:** 72  
**Width:** 37.6 cm  
**Gross weight:** 11 kg  
**Height:** 26.4 cm  
**Nett weight:** 5.904 kg  
**Tare weight:** 5.096 kg

## Inner Carton

**Length:** 16.5 cm  
**Number of consumer packagings:** 6  
**Width:** 7.8 cm  
**Height:** 22.8 cm  
**Nett weight:** 0.492 kg  
**Gross weight:** 0.84 kg  
**Tare weight:** 0.348 kg  
**EAN:** 87 12581 57365 2

## Packaging dimensions

**Height:** 22.2 cm  
**Packaging type:** Blister  
**Type of shelf placement:** Both  
**Width:** 15.7 cm  
**Depth:** 1.18 cm  
**Number of products included:** 1  
**EAN:** 87 12581 56461 2  
**Gross weight:** 0.123 kg  
**Nett weight:** 0.082 kg  
**Tare weight:** 0.041 kg

## Accessories

**User Manual:** 15 languages

