Register your product and get support at

www.philips.com/welcome

S9H

Quick start guide

PHILIPS

Important safety instructions

- Use only the power supply listed in the user instructions.
- Do not allow the product to come into contact with liquids.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instrucions.
- Hereby, WOOX Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. You can fi nd the Declaration of Conformity on www.p4c.philips.com.

1 Get started

Connect the charger

Charge your phone

Configure your phone

1 Press 📞 until you see the Philips wordmark.
2 Set the language.
3 Set date and time.

Charge 5 hours

> 84%

36% - 52%

68% - 84%

20% - 36%

52% - 68%

< 20%

Flashing: low battery
Scrolling: charging in progress

2 Register additional handsets

You can register up to 4 additional handsets to the base station.

1 Select **[Menu]** > ⚙ > **[Registration]** > **[Register]**, then press **[OK]** to confirm.
2 Press and hold •)) on the base station for 5 seconds.
3 Enter the system PIN/passcode (0000). Press **[Clear]** to make corrections. Press **[OK]** to confirm the PIN/passcode.
   ↳ Registration is complete in less than 2 minutes. The base automatically assigns a handset number to the handset.

Note

- If the PIN/passcode is incorrect or no base is found within a certain period, your handset displays a notification message. Repeat the above procedure if registration fails.
- The preset PIN/passcode is 0000. It cannot be changed.

User manual

www.philips.com/support

For more information, refer to the S9/S9A user manual online.

Online

Register at www.philips.com/support to get the free Philips Phone Manager software for your computer and the latest phone software for your phone.

PHILIPS

CE 0168

UMS_S9H
12_EN_V3.0
WK13521