



Quick Start Guide


A Select power supply




D Play USB




B Listen to radio



E Record from CD to USB



C Play disc



- To record one track, play a track and press **USB REC**.
- To record all tracks, stop play and press **USB REC**.
- To record fast, hold down **USB REC** for more than 2 seconds.



© 2009 Koninklijke Philips Electronics N.V.
All rights reserved.

