


Quick start guide



1 Connect






Multi-handset version only.

Configure your phone



- **1** When using your phone for the first time, you see a welcome message (country dependent).
- 2 Set the country and language if prompted.
- 3 Set the date and time.
 - If the time is in 12-hour format, press * key to select [am] or [pm] (country dependent).

Charge your phone



> 84%

68% - 84%

52% - 68%

Flashing: low battery Scrolling: charging in progress 36% - 52%

20% - 36%

< 20%

Pair your S8A with your mobile phones

Make sure the Bluetooth function of the mobile phones is activated and in searching status. Then you can do the pairing in this way:

- 1 Press and hold 3 on the base station until the Bluetooth LEDs on the base station flash.
- 2 On the mobile phone, select **S8A** and connect.
- **3** Enter the PIN code (0000) on the mobile phone, if necessary.
 - → When S8A and the mobile phone are paired,
 - \$12 or \$12 is displayed on the handset screen. The corresponding LED on the base station remains steadily on.



- When the Bluetooth device list is full, remove some mobile phone names before pairing can start.
- If the name of S8A exists in your mobile phone, you have to remove it from your mobile phone. Then you can do the pairing again.

4 Enjoy

Call

Normal call

Press 🍮 / 🕩 and dial the phone number.

Predial call

- 1 Dial the phone number.
- 3 Press ♣ / ▷ to dial out the call.

Answer a call

To answer a call, press $\stackrel{\bullet}{\smile}$ / $\stackrel{\bullet}{\vartriangleleft}$ when the phone rings.

End a call

- To end a call, press ____.
- Place the handset to the base station.

Adjust the earpiece volume

Press \bigcirc or \bigcirc to adjust the volume during a call.

Add a contact in the phonebook

- 1 Press ? [Option] > [Add new].
- 2 Follow on-screen instructions.

Telephone answering machine

Record an announcement

- 1 Select [Menu] > \square > [Announcement].
- 2 Follow on-screen instructions.

Listen to the incoming messages

Delete an incoming messages

- 1 When you listen to the message, select **[Option]** to enter the options menu.
- 2 Select [Delete], then press [OK] to confirm.

User manual



Online



Refer to the user manual that came with your new phone.

www.philips.com/support

C € 0168



Reproduction in whole or in part is prohibited without the written consent of the copyright owner. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners. All rights reserved.

© 2012 Koninklijke Philips Electronics N.V.

OSG S8A

QSG_S8A 05_EN_V1.0 WK12261