

# www.philips.com/welcome





EN Quick Start Guide














# **English**

### Connect wires 1

1 Check the car's wirings carefully, then connect them to the unit.

### Mount in the dashboard

- 1 If the car does not have an on-board drive or navigation computer, disconnect the negative terminal of the car battery.
- 2 Ensure that the horizontal slant of the car dashboard opening is between 0 and 20 degrees. The unit cannot be used if the dashboard opening's slant angle is above 20 degrees.
- Fix the plastic clips and base support (removed from the original in-car system) to the main unit.
- Fix the mounting brackets (removed from the original in-car system) to the left and right side panels of the main unit.
- Fix the exhaust outlets of the original airconditioner to the two openings. 4
- Fix the hazard warning switch (removed from the original in-car system) to the main unit.
- 7 Slide the unit into the dashboard and fix it to the car.
- 8 Reconnect the negative terminal of the car battery.

### Turn on

- 1 Press and hold **O/MUTE/VOL** to turn on the unit.
  - The available OSD (On-Screen Display) languages are displayed.



- 2 Tap a language to select.
- To turn off the unit, press and hold Φ/ MUTE/VOL.

# Set date and time

1 Tap ♠ to display home menu.



- 2 Tap [Settings].
- **3** Tap **[Time]**.
  - → The date/time setup menu is displayed.



#### Set date

- 1 Tap **[Date]**.
- 2 Tap on the displayed date information.
- 3 Tap ♠ or ♥ to set year, month and day.

#### Set clock mode

- 1 Tap [Clock mode].
- 2 Tap on [12Hr] or [24Hr] to select clock mode

#### Set time

1 Tap [Time].

- Tap on the displayed time.
- 3 Tap ♠ or ♥ to set hour and minute.

# Use map



- You may need to upgrade the map (sold separately) before using it.
- 1 In the main menu, tap [Navigation].
  - → The navigation menu is displayed in a few seconds.
- 2 See the map manual to operate the navigation tool.

### Listen to Radio

- 1 Tap ♠ to display the home menu.
- 2 Tap [Radio].
  - → Band and frequency information is displayed.



- 3 Tap on FM or AM to select band:
- 4 Briefly tap ◀ or ▶ to tune to a radio station by step.

# Play disc 6

You can play video, audio or images stored on the following discs:

- DVD video, DVD-R, DVD-RW
- VCD
- Audio CD, CD-R, CD-RW
- 1 Insert a disc into the disc slot with the label side facing up.
  - → Play starts automatically.

# Connect USB device 7

- 1 Open the USB/SDHC socket cover.
- Insert the USB storage device to the USB socket.
  - → Play starts automatically.

# Insert SD/MMC card 8

- Open the USB/SDHC socket cover.
- Insert the SD/MMC card into the card slot.
  - → Play starts automatically.

### Make a call

- 1 Pair the phone with the unit.
- 2 Tap 🖈 to display the home menu.
- 3 Tap [Bluetooth].
  - → The Bluetooth menu is displayed.



- 4 Tap ♠ or ♥ to select the paired phone, then tap ●.
- 5 Tap ♠ or ♥ to search for phone number from the following list:
  - [Missed calls]
  - [Received calls]
  - [Dialed calls]
  - [Phone book]
  - [Sim phone book]
  - [Local phone book]

Or tap  $\blacksquare$  to dial number directly, then tap  $\frown$  to dial.

# Answer a call

By default, the in-car system answers all incoming calls automatically.

- 1 If there is incoming call, [Incoming call...] flashes on the screen. Speak into the Bluetooth microphone.
- When conversation ends, tap **•** (red) to terminate the call.



