Philips Sport audio player

3GB*

















Designed for movement

Designed for freedom of movement, the 3GB* PSA610 lets you enjoy up to 1500 songs for all your favourite sports moments. With a shock-absorbing design, enjoy your favourite music even during the most vigorous workouts.

On the move - always

- · Built-in talking stopwatch
- Intuitive 'no-look' music control via the rocking lens
- Shock absorbing design
- ShockLock for 100% shock-free music
- Comes with sport armband and sport headphones

Your music, your moves

- Plays up to 1500 songs*
- 3GB* built-in memory
- Enjoy up to 12-hour music playback
- · Navigation based on track, artist, album, genre or playlist
- SuperScroll™ navigation finds songs in a simple, fast way
- Fast downloads from your PC via USB2.0
- PlaysForSure* with Windows XP only



Specifications

Picture/Display

- Backlight
- · Backlight colour: Blue
- Indications: artist name, battery status, DBB, frequency, preset station, time, track, volume
- Resolution: 96 x 64 pixels
- · Type: LCD

Sound

- Bass enhancement: Digital Bass Boost
- Equalizer settings: RnB, Classic, Hip Hop, Jazz, Rock
- Frequency response: 20 20 000 Hz
- Output power (RMS): 2 x 5mW
- Signal to noise ratio: 80
- Volume Control: digital

Audio Playback

- Compression format: MP3, Windows Media™ Audio
- ID3 Tag support: Album title and artist name, Track title and artist name
- MP3 bit rates: 32-320 kbps and VBR
- ShockLock
- WMA bit rates: 32 192 kbps

Storage Media

- Hard Disk Capacity: 3 GB
- Music memory capacity, MP3: up to 750 MP3 (128kbps & 4 min.)
- Music memory capacity, WMA: up to 1500 WMA (64kbps & 4min.)
- Built-in memory type: Hard disc

Connectivity

- Headphone: 3.5 mm
- USB: USB 2.0

Convenience

- Function: Keypad lock
- Lines of text: 4

Accessories

- CD-ROM: AY4498

- AC/DC adaptor/charger: AY4107

Software

- Device manager
- Windows Media Player 10

Green Specifications

Lead-free soldered product

System Requirements

- CD-ROM drive
- Internet connection
- Microsoft Internet Explorer: 6.0 or later
- PC OS: Windows® XP (SPI or higher)
- Sound card
- USB: Free USB port
- Video card

- Adaptor type: 100 240V
- Battery capacity: 610 mAh
- Battery Type: Li-ion
- Charging time: 4 hrs full, I hr fast charge hr
- Rechargeable

Dimensions

- Packaging type: D-box
- Product dimensions (W \times H \times D):

 $70.5 \times 29.9 \times 70.5 \text{ mm}$

- Product weight: 0.092 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D):
- 155 x 155 x 96 mm
- Master carton dimensions: 168 x 168 x 316.5 mm

- Armband: AY4224
- Headphones: HJ025
- USB cable: AY3915



Version: 10.0

12 NC: 9073 101 01826 EAN: 87 10895 87603 2 © 2007 Koninklijke Philips Electronics N.V.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

SA610/00

Product highlights

Built-in talking stopwatch


Activate the built-in talking stopwatch feature via the strategically positioned button on the top left of the player. The stopwatch relays the elapsed running time via your headphones. You don't even need to look at your player. To keep you motivated in any mode, the talking stopwatch can be used either with or without music playback.

'No-look' rocking lens

Enjoy a hassle free workout and take accurate control of your music on the move via your player's intuitive 'nolook' rocking lens. Designed to keep you moving and motivated, the rocking lens provides discreet and easy access to multiple functions on the player without disrupting your workouts. For a true 'no look' experience, simply tap on the guiding points of the rocking lens marked with a small bump for convenient and accurate music control.

ShockLock

Enjoy 100% shock-free music on the go and even during the most vigorous workouts. No need to worry about damaging the hard disc of your HDD player. Once you've selected your favourite songs to motivate your workout, simply press the 'Hold' button on your HDD player and select the ShockLock mode. Your music selection will be automatically loaded into the HDD player's buffer memory. From this moment on, the hard disc will be locked in ShockLock mode to protect it from shock and vibration. Enjoy your workouts free from shock.



* IGB = I billion bytes; available storage capacity will be less.
* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of

charge cycles vary by use and settings.
Storage capacity based on 4 minutes per song and 64 kbps WMA or 128 kbps MP3 encoding.
The PlaysForSure, Windows Media and the Windows logo are

trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Actual transfer speed may vary based on your operating system and software configuration.

