

PHILIPS

Lens cleaner

CD/DVD

2-brush system

SVC2330



Cleans and protects your CD/DVD player

Regular cleaning of your CD/DVD player's lens ensures optimum performance of your equipment. It is important to keep the optical laser lens clean and dust-free. This dry-brush system safely removes dust, debris and other contaminants.

Maintain original sound quality

- Audio system check for correct setting

Maintain original sound and video quality

- Safe dry brush cleaning system

Easy to use

- Voice instructions in 14 languages

Highlights


Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD player's laser lens, leaving it clean and performing optimally.

Audio system check

The audio system check determines whether the speakers are properly adjusted.

Voice instructions



The voice instructions on this easy-to-use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.

Specifications

Storage Media

Supported formats: CD-Audio, CD-ROM, DVD-ROM

Outer Carton

EAN: 87 12581 57360 7
Length: 54.3 cm
Number of consumer packages: 72
Width: 37.6 cm
Gross weight: 11 kg
Height: 26.4 cm
Net weight: 5.904 kg
Tare weight: 5.096 kg

Inner Carton

Length: 16.5 cm
Number of consumer packages: 6
Width: 7.8 cm
Height: 22.8 cm
Net weight: 0.492 kg
Gross weight: 0.84 kg
Tare weight: 0.348 kg
EAN: 87 12581 57365 2

Packaging dimensions

Height: 22.2 cm
Packaging type: Blister
Type of shelf placement: Both
Width: 15.7 cm
Depth: 1.18 cm
Number of products included: 1
EAN: 87 12581 56461 2
Gross weight: 0.123 kg
Net weight: 0.082 kg
Tare weight: 0.041 kg

Accessories

User Manual: 15 languages

