





Registre seu produto e obtenha suporte em
www.philips.com/welcome






Guia rápido do usuário

PHILIPS

DS1600



- | | | |
|---|--|--|
| ✓ | iPod nano 7th Generation
iPod touch 5th Generation
iPhone 5
iPad mini
iPad 4 | iPod classic
iPod touch (2nd, 3rd, 4th Generation)
iPod nano (1st, 2nd, 3rd, 4th, 5th, 6th Generation)
iPod with video, iPod with color display
iPod mini
iPhone 3G, iPhone 3GS, iPhone4, iPhone 4S
iPad 1, iPad 2, new iPad |
|---|--|--|



2013 © WOXX Innovations Limited. Todos os direitos reservados.

A Philips e o emblema em formato de escudo da Philips são marcas registradas da Koninklijke Philips N.V. e são usadas pela WOXX Innovations Limited sob a licença da Koninklijke Philips N.V.

DS1600_78_SUM_V1.0





S1600_78_QSG_V1.0.indd 7-12

A lista completa e atualizada dos nossos postos autorizados está disponível no site www.philips.com.br/suporte