
Quick start guide




What's in the Box?


You should find these items upon opening the box.







Step B Setup






Playing a disc

Press **OPEN**•**CLOSE** to open the disc tray and load up to two discs on the individual disc trays. To load the third disc, press **DISC CHANGE**.

→ Make sure the label side of each loaded disc is facing up.

Press **OPEN**•CLOSE again to close the disc tray.



Use **DISC 1/2/3** to select a disc for playback.

4


To stop playback, press

Programming and tuning to radio stations

Press **TUNER** repeatedly (or **TUN** on the remote control) to select the tuner source.

Press **PROG** for more than two seconds to program all available stations in order of waveband.

Press **ALBUM/PRESET +/-** (or **ALB/PRESET +/-** on the remote control) until the desired preset station is displayed.



Тір

Detailed playback features and additional functions are described in the accompany owner's manual.

