



## CD cont.

SCOTT .....	0767 0968
SEARS .....	0569 0570 0379
SHARP .....	0569 0570
SHERWOOD .....	0769 0570
.....	0471 0272 0587
SHURE .....	0670
SONY .....	0372 0880 0081 0681
STS .....	0490
SYMPHONIC .....	0572
TEAC .....	0269 0570 0571
TECHNICS .....	0572 0672 0772 0287
TECHNICS .....	0273 0974 0683 0887
THETADIGITAL .....	0774
TOSHIBA .....	0773
VICTOR .....	0869
YAMAHA .....	0168 0872
.....	0972 0074 0286
ZENITH .....	0269 0674
.....	0577 0080 0686

## AUDIO

AIWA .....	0585 0885 0786 0687
APEX .....	0245
APPLE IPOD .....	0180
BOSE .....	0868
CARVER .....	0184
CENTRIOS .....	1107 0087
CITIZEN .....	0284
CRITERION .....	0446
DENON .....	0981 0383 0886
DELPHI .....	0472
FISHER .....	0083 0783
GOLDSTAR .....	0278
HARMAN KARDON .....	0082 0483
IPOD .....	0090
JVC .....	0680 0982 0583
KENWOOD .....	0969 0482 0283
.....	0484 0884 0588
KOSS .....	0143
MAGNAVOX .....	0281 0083 0193 0277
MARANTZ .....	0470 0084
MITSUBISHI .....	0389
NAD .....	0773 0575 0975
NEO .....	0174
NEXXTECH .....	1107 0679 0789 0480
.....	0580 0584 0087 0187
NORCENT .....	0192
ONKYO .....	0182 0872 0882 0890
OPTIMUS .....	0368 0376 0476 0576
PANASONIC .....	0776 0876 0077 0980
.....	0987 0088 0790 0696
PHILIPS .....	0177 0083
JASCO .....	0983 0084 0184
PIIONEER .....	0385 0489 0990
RADIO SHACK .....	0272 0077 0980
.....	0282 0188 0288 0388
.....	0488 0189 0489 0589
RCA .....	0373 0274 0878 0779 0181
.....	0384 0186 0288 0388 0688 0788
.....	0888 0189 0489 0589 0546 0191
REALISTIC .....	0883

RIO .....	0142
SABA .....	0091
SAMSUNG .....	0047
SANYO .....	0172
SCOTT .....	0478
SHARP .....	0678 0070 0582
SHERWOOD .....	0272 0282 0487 0587
SKYFI .....	0174
SONY .....	0933 0479 0579 0180
.....	0381 0481 0581 0984
.....	0085 0185 0285 0982
TAO .....	0174
TEAC .....	0672 0382 0187 0287 0387
TECHNICS .....	0780 0682 0183
.....	0983 0987 0088
TEVION .....	0446
VENTURER .....	0176
XM RADIO .....	0472 0174
YAMAHA .....	0781 0881 0485 0685
.....	0785 0286 0386 0486 0586
ZENITH .....	0269 0674 0576 0577 0178
.....	0278 0080 0083 0380 0686 0142

## CABLE

ABC .....	0747 0947 0048 0148 0248
ADDELPHIA .....	0852 0752
ALLEGRO .....	0054 0154
AMERICAST .....	0354
ANTROXON .....	0448 0548
ARCHER .....	0448 0548 0648 0748
AT&T .....	0752
BELL SOUTH .....	0354
CABLETEENNA .....	0448
CABLEVIEW .....	0448
CABLEVISION .....	0252
CENTURY .....	0748
CITIZEN .....	0748
COGECO .....	0752
COLOR VOICE .....	0848 0948
COMCAST .....	0752
COMTRONICS .....	0049 0149
CONTEC .....	0249
DIGITAL MUSIC EXPRESS .....	0053
EASTERN .....	0349
EVERQUEST .....	0049
GARRARD .....	0748
GE ELECTRONICS .....	0548
GEMINI .....	0255 0549
GE .....	0556
GENERAL INSTRUMENT (GI) .....	0556
.....	0552 0747 0148 0752 0952
.....	0453 0654 0754 0083 0084 0947
HAMLIN .....	0747 0649 0749 0849
HITACHI .....	0947
ILICO .....	0252
JASCO .....	0748
JERROLD .....	0552 0747 0148 0453
.....	0947 0048 0653 0254
MAGNAVOX .....	0150
MEMOREX .....	0250
MOTOROLA .....	0552 0148 0952 0453
.....	0654 0754 0048 0752 0254 0947
MOVIE TIME .....	0350
NSC .....	0350
OAK .....	0249 0550
PAK .....	0654
HARMAN KARDON .....	0083

## SAT/DTV/WebTV

Where codes are shown like this [###] each one can be used if you have 2 or more of the SAME device.	
AMPICA .....	0159
BELL EXPRESSVU .....	0067 0366
SIS .....	0167 0464
CHANNEL MASTER .....	0359
SYLVANIA .....	0459 0559
CHAPPARAL .....	0657 0757
CHEYENNE .....	0757
DRAKE .....	0857 0059 0360
DIREAMBOX .....	0663
DREAMVIEW .....	0863 0864 0564 0763
UNITED .....	0963 0259 0260 0263 0962
.....	0664 0065 0265 0465 0765 0866
ULTIMATETV .....	0966 0367
UNIDEN .....	0964 0958 0762
.....	0361
VIDEO CIPHER II .....	0063 0059
WEB TV .....	0863 0160
ZENITH .....	0363 0065 0267 0161
.....	0266 0857 0059 0360 0165
DISH NETWORK .....	[0167] [0366]
.....	0464 0862 0067 0460 0560 0660

## DVD

DISHPRO .....	0460 0560 0660 0067
PARAGON .....	0245 0859
DX ANTENNA .....	0458 0859
ECHOSPHERE .....	0464
ECHOSTAR .....	[0167] [0466]
PHILIPS-MAGNAVOX .....	0152 0055
.....	0464 0862 0067 0460 0560 0660
PIONEER .....	0449 0252 0950 0051
PULSAR .....	0558 0157 0247
RADIO SHACK .....	0152 0055 0154
RCA .....	0647 0748 0352
REALISTIC .....	0548
REGAL .....	0849
REGENCY .....	0349
REMBRANDT .....	0947
ROGERS .....	0252
RINCO .....	0250
SAMSUNG .....	0049 0051
SCIENTIFIC ATLANTA .....	0049
.....	0252 0155 0852 0248 0251
SIGNAL .....	0049
SIGNATURE .....	0947
SL MARX .....	0049
SPRUCER .....	0647
STANDARD .....	0551
STARCOM .....	0747 0453
STARLIGHT .....	0352
STARTRAK .....	0253
STARTRAK .....	0253
TANDY .....	0651
TELEVIEW .....	0049
TEXSCAN .....	0551
TIME WARNER .....	0252
TOCOM .....	0048 0751 0952 0653
TOSHIBA .....	0250
TRM8 .....	0350
UNIKA .....	0448 0548 0748
UNITED CABLE .....	0747
UNIVERSAL .....	0448 0548 0648
VIDEOWAY .....	0148 0851 0054
VIEWSTAR .....	0149 0150 0350 0651
VIDEO TECH .....	0656
VIDEOTRON .....	0252
ZENITH .....	0951 0154 0748
ZENITH .....	0250 0753 0853 0953
ZENITH NETWORK .....	0354

HITACHI .....	0042 0342 0444 0543
HITEKER .....	0146
HUMAX .....	0892
ILO .....	0597 1608
INFINITY .....	0343
INSIGNIA .....	0142 0247
REGENT .....	0793 0644 0192
REOC .....	0644 1608
RIO .....	0843
R/TECHNOLOGY .....	0142
ROSEN .....	0694
ROTEL .....	0242
SABA .....	0640 0990 0191
SAMSUNG .....	0342 0047 0895
.....	0997 0790 0147
KISS .....	0444
KLH .....	0644 0292 0240
KONKA .....	0642 0742
KOSS .....	0842 0942 0192
KXD .....	0091
LASONIC .....	0746 4096
LENOSXX .....	0794 0145
LG .....	0898 0342
LINN .....	0945
LITEON .....	0899 0891 0491 0597 1508
SONIC BLUE .....	0395
SONY .....	0300 0400 0500
.....	0541 0200 0440
SOUNDSTORM .....	0692 0792
SUNGALE .....	0946
SUPERSCAN .....	0297
SEARS .....	0041 0247
SEG .....	0041 0444
SELECTRON .....	1309 1409 1509
.....	1609 1709 1809 1909
SHARP .....	0342 0047 0895
SHERWOOD .....	0341 0391 0942
SHINCO .....	0644
SHINSONIC .....	0644
SONIC BLUE .....	0395
SONY .....	0300 0400 0500
.....	0541 0200 0440
SOUNDSTORM .....	0692 0792
SUNGALE .....	0946
SUPERSCAN .....	0297
SUPERSONIC .....	0096
SV2000 .....	0247
SYLVANIA .....	0247 0447
SYMPHONIC .....	0247 0447 0591
TEAC .....	0042 0546
TECHNICS .....	0644
TECHWOOD .....	0944 1708
TERAPIN .....	0895
LITEON .....	0891 0491 0597
MAGNAVOX .....	[0599] [0699]
MEDION .....	0991 0597
MEMOREX .....	1606
MUSTEK .....	0041 0441
HUMAX .....	0892
ILO .....	0597
JVC .....	0691 1808
KXD .....	0091
LG .....	0392
LITEON .....	0891 0491 0597
MAGNAVOX .....	[0599] [0699]
MEDION .....	0991 0597
MEMOREX .....	1606
MUSTEK .....	0041 0441
ORITRON .....	1607
PANASONIC .....	0340
PHILIPS .....	[0599] [0699]
PHILIPS-MAGNAVOX .....	[0599] [0699]
PHIONEER .....	0399 0592 1010
ORION .....	0041
ORITRON .....	0143 1607
EMERSON .....	0591 0247 0447
ESA .....	0297
FARENHTEH .....	0697
FISHER .....	0243
FUNAI .....	0247 0447
GE .....	0542 0644
GOLDSTAR .....	0142
GO-VIDEO .....	0744 0395 0798 0047
.....	0891 0791 0342 0244 0147
GPX .....	0295 0096
GRADIENTE .....	0143
GREENHILL .....	0644
HAZ .....	0746 0846
HAIER .....	0145
HARMAN KARDON .....	0395

PROSONIC .....	0294
PYLE .....	0692
RADIO SHACK .....	0546 0946
RCA .....	0542 0644 0546
0946 0693 0690	
ART& .....	0938
HUGHES .....	0659
HUMAX .....	0892
PANASONIC .....	0938 0340
PHILIPS .....	[0738] [0036] [0136]
PIONEER .....	0592 0399
RCA .....	0542
REPLAYTV .....	0938
SONIC BLUE .....	0938
SONY .....	0838 0367 0537
TIVO .....	0738 0838 0036 0136
.....	0567 0999 0992 0592
TOSHIBA .....	0999

## DVR

Where codes are shown like this [###] each one can be used if you have 2 or more of the SAME device.

ART& .....	0938
HUGHES .....	0659
HUMAX .....	0892
PANASONIC .....	0938 0340
PHILIPS .....	[0738] [0036] [0136]
PIONEER .....	0592 0399
RCA .....	0542
REPLAYTV .....	0938
SONIC BLUE .....	0938
SONY .....	0838 0367 0537
TIVO .....	0738 0838 0036 0136
.....	0567 0999 0992 0592
TOSHIBA .....	0999

## DVD-Recorders + RW

Where codes are shown like this [###] each one can be used if you have 2 or more of the SAME device.

APEX .....	0495
ASPIRE .....	0994
BROKSONIC .....	0398
CENTRIOS .....	0796 1607 1707
COBY .....	0091
CYBERHOME .....	0595
EMERSON .....	0591
GO-VIDEO .....	0744 0891 0791
HITACHI .....	[0316 0626] [0316 0327]
CURTIS MATHES .....	0437
DAEWOO .....	[0505 0826]
.....	[0415 0529]
DIAMOND VISION .....	[0810 0291]
DURABRAND .....	[0916 0126]
ELECTROHOME .....	0027
ADVENT .....	0893
APEX .....	[0023 0741]
AXION .....	[0319 0793]
BROKSONIC .....	0041
CHANGHONG .....	0428
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	0128 0228 0632 0134 [0505 0826]
ADVENT .....	0927
AXION .....	[0023 0741]
BROKSONIC .....	0041
CHANGHONG .....	[0023 0741]
CLASSIC .....	[0023 0741]
DAEWOO .....	[0615 0066]
DIAMOND VISION .....	[0622 0496]
.....	[0810 0291]
DURABRAND .....	[0916 0126]
EMERSON .....	0324 0924 0027 0028
.....	01