

Philips
Micro Hi-Fi System

MP3/WMA-CD playback
Compact design

MCM108D



Dock and play your GoGear or iPod

Dock your GoGear or iPod player. Listen to your music from one simple control. Great sound and sophisticated design. Sit back and relax, enjoy your music all day, your way.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

Wake up to CD or radio tunes

- Wake up and sleep timer functions
- Stereo tuning with digital readout

Fits any space, any lifestyle

- Dock and play your GoGear or iPod players
- Compact design

PHILIPS

Specifications

Sound

- Output Power: 2x2watts rms
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 3.5" woofer

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Cradle playback mode: Fast forward and backward, Next and Previous track, Play and Pause, Program play, Repeat, Shuffle play, Charging GoGear, Charging iPod

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

Connectivity

- Headphone: 3.5 mm
- Other connections: Cradle connection, FM fixed

pigtail antenna, AM Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: White

Accessories

- Included accessories: FM/MW Antenna
- Remote control: 20-key with battery
- User Manual: English and Chinese
- Cradle: Cradle and adaptors for GoGear and iPod
- Cables: Docking cable

Dimensions

- Set dimensions (W x H x D): 150 x 153 x 244 mm
- Main speaker dimensions (W x H x D): 150 x 153 x 204 mm
- Packaging dimensions (W x H x D): 535 x 200 x 301 mm
- Weight incl. Packaging: 5.5 kg

Power

- Power supply: 100-240VAC, 50/60Hz

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-02-10

Version: 1.0.4

12 NC: 8670 000 27432
EAN: 87 12581 31828 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com