



1




• 仅在关机模式下为播放机充电。


2




2




2




3




2




3




4



2




3



5



2




© 2009 Koninklijke Philips
Electronics N.V.
All rights reserved.



PET739_QSG_ZH-CN_V1.2

6



7



Be responsible
Respect copyrights