



Specifications are subject to change without notice
 © 2015 Koninklijke Philips Electronics N.V.
 All rights reserved.

SDV5228/27

Always there to help you

SDV5228/27

Enjoy your product and get support at
www.philips.com/welcome



EN User manual

FR Mode d'emploi

ES Manual del usuario

PHILIPS





Fig.1

EN

- 1 Connect the antenna and the TV receiver with the coaxial cable of the antenna and the coaxial cable of the amplifier.
- 2 Connect the DC plug to the amplifier and the power supply to a 110V AC outlet.
- 3 Turn the TV to the desired channel.(Fig.1)

FR

- 1 Reliez l'antenne et le récepteur TV au moyen du câble coaxial de l'antenne et du câble coaxial de l'amplificateur.
- 2 Branchez la fiche CC sur l'amplificateur et l'alimentation sur une prise 110 V CA.
- 3 Allumez le téléviseur et choisissez la chaîne souhaitée. (Fig.1)

ES

- 1 Conecte la antena y el receptor de televisión con el cable coaxial de la antena y el cable coaxial del amplificador.
- 2 Conecte la toma CC al amplificador y la fuente de alimentación a una toma de CA de 110V.
- 3 Ponga el televisor en el canal deseado. (Fig.1)