




Quick Start Guide


1





2



1




2




3



1




2



SETUP


General	Status	Personal	Display	Exit
General Setup Page				
OSD Lang	Eng	English		
Screen Saver	On	Timeout		
Mouse	On	Enabled		
Angle Mark	On	Enabled		




4




1




2



3



5



6



Be responsible
Respect copyrights

© 2010 Koninklijke Philips Electronics N.V.
All rights reserved.



PD9030_51_QSG_V1.0