







Register your product and get support at
www.philips.com/welcome

HTS3560




Quick Start


PHILIPS




FM Antenna




Power cord



Video Cable




HDMI Cable




PHILIPS



1






2



3





2

1

SOURCE

TV

AV

2

3

4

HOME THEATER

5

6

HOME THEATER

7

8



HOME THEATER

Video Setup	Menu Language	English
Audio Setup	Audio	•
Network Setup	Subtitle	•
EasyLink Setup	Disc Menu	•
Preference Setup	Parental Control	•
Advanced Setup	Screen Saver	•
	Auto Subtitle Shift	•
	Change Password	•



Menu Language	Auto (ENG)
Audio	English
Subtitle	Melayu
Disc Menu	ภาษาไทย
Parental Control	中文 (简体)
Screen Saver	中文 (繁體)
Auto Subtitle Shift	
Change Password	




3

DISC



FM





Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgsna_1027/98_v2

Be responsible
Respect copyrights

