# **Docking Entertainment System**


Register your product and get support at www.philips.com/welcome

QUICK START
MISE EN SERVICE RAPIDE
INICIO RÁPIDO
SCHNELLSTART
SNELSTART
AVVIVO RAPIDO



Thanks for buying **Philips AJ301DB Docking Entertainment System**Our **Quick Start** guides you through just some of the features on the set.
Please read our instruction booklet to really rise & shine!





### **ENGLISH**

### Step A

 Connect the supplied mains adapter to the set's18V DC jack and the plug into a wall outlet.

### Step B

### How to set the Clock & Alarm time

- Press and hold TIME SET or ALM1 / ALM2 until the hour digits flash.
- **2.** Press and hold  $\blacktriangleleft \blacktriangleleft \blacktriangleright \blacktriangleleft$  to adjust time.
- 3. Press TIME SET or ALM1 / ALM2 to confirm.
- **4.** Repeat the **steps 2~3** to complete all the other time items setting.

### Step C

# Selecting the Alarm mode

In standby mode, slide the **DOCK/BUZZER/ TUNER** to select desired mode

#### Helpful hints:

- If you have selected TUNER alarm mode, make sure you have properly tuned to a station before turning off the set (See Tuning to radio station).
- If you have selected DOCK alarm mode, make sure you have docked the compatible player, or buzzer mode will be selected automatically.

### 3 ways to switch off the alarm

- Either press briefly: POWER or REPEAT ALARM/ BRIGHTNESS CONTROL.
- Press ALM1 or ALM2.

### Step D

### Tuning to radio station

- 1. Press TUNER/AUX once to switch on the radio.
- Press ◄ ►► one second or more to tune to your station.
- To store a preset, hold down briefly on a **PRESET** button **1-5** until you hear a double beep.

### Step E

## Playing Apple iPod using AJ301DB

- Select the correct dock adaptor from the supplied, then snap the adaptor into the dock to provide a snug fit for the player.
- The iPod connector is pre-installed with the AJ301DB main unit.
- The indication on the adaptor's back fits specific iPod player.
- Snap the compatible iPod player into the dock connector:
- 3. Press **DOCK** to select the dock mode.
- The connected player will play automatically

#### Helpful hints:

- By using the buttons (►II, I◄◄, ►►I and VOLUME) on the AJ301DB and its remote control, the following iPod playback features are available: Play/Pause, selecting next/previous track, fast forwarding/rewinding and changing volume.
- Refer to the user manual supplied for detailed descriptions of "Compatible portable player", "Changing the dock", "Selecting the correct dock adaptor" and the important notes for dock operation.

