





Register your product and get support at
www.philips.com/welcome

DCM2055








1. Press and hold the **PROG/CLOCK SET** button for 3 seconds.
2. Press the **LEFT** and **RIGHT** arrow buttons to adjust the time.
3. Press the **PROG/CLOCK SET** button again to confirm the setting.

The display shows the time as 12:00.



PHILIPS



©2011 Koninklijke Philips N.V.
All rights reserved.

DCM2055_05_QSG_V1.0

