

Philips  
CD Soundmachine with  
Dynamic Bass Boost

• MP3

AZ1835



## Rip your favorite CDs to MP3

With the advanced AZ1835 CD Soundmachine, you can now convert your favorite CDs to MP3 music with the single touch of a button, no computer is required !

### **MP3 music at your fingertips**

- CD ripping for one-touch MP3 digital recording
- Enjoy MP3/WMA music directly from your portable USB drives
- 10 hours of MP3-CD or 20 hours of WMA-CD music

### **Bass sound experience**

- Dynamic Bass Boost for deep and dramatic sound

### **Easy to use**

- FM/MW tuner for radio enjoyment
- Multi-functional LCD display
- Handy remote control

# PHILIPS

# Specifications

## Connectivity

- USB: USB host

## Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play

## Sound

- Output power (RMS): 2X1.0W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

## Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

## Tuner/Reception/Transmission

- Tuner Bands: AM, FM
- Antenna: FM Antenna

## Convenience

- Display Type: LCD

## Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate
- Remote control

## Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

## Dimensions

- Packaging dimensions (W x H x D): 406 x 200 x 270 mm
- Product dimensions (W x H x D): 361 x 152 x 239 mm
- Weight: 2.2 kg
- Weight incl. Packaging: 2.8 kg

# Highlights

## CD ripping

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch operation and no computer needed.

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 2.0.5

12 NC: 9073 101 02535  
UPC: 6 09585 11152 3

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)

\* Music with Digital Right Management not supported.