









Be responsible  
Respect copyrights

Reproduction in whole or in part is prohibited without the written consent of the copyright owner.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.  
Product information is subject to change without prior notice.  
© 2011 Koninklijke Philips Electronics N.V.  
All rights reserved.




Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)

DS3510



- Quick start guide **English**
- Lynvejledning **Dansk**
- Schnellstartanleitung **Deutsch**
- Guía de configuración rápida **Español**
- Guide de démarrage rapide **Français**
- Guida di avvio rapido **Italiano**
- Snelstartgids **Nederlands**
- Snabbstartguide **Svenska**
- Stručný návod k rychlému použití **Čeština**
- Guia de início rápido **PT-BR**
- Οδηγός γρήγορης έναρξης **Ελληνικά**
- Pikaopas **Suomi**
- Rövid üzembe helyezési útmutató **Magyar**
- Skraćona instrukcja obsługi **Polski**
- Manual de Inicio Rápido **Português**
- Краткое руководство **Русский**
- Stručná úvodná príručka **Slovensky**
- 요약 설명서 **한국어**
- 快速啟用指南 **繁體中文**
- 快速启用指南 **简体中文**

PHILIPS



- iPod touch (1G, 2G, 3G, 4G)
- iPhone, iPhone 3G, iPhone 3GS
- iPhone 4
- iPod nano 1G
- iPod nano 2G
- iPod nano 3G
- iPod nano 4G
- iPod nano 5G
- iPod nano 6G
- iPod mini
- iPad

