






Specifications are subject to change without notice  
© 2015 Koninklijke Philips Electronics N.V.  
All rights reserved.

SDV1226/27



## Overview

EN

- 1 VHF antenna
- 2 UHF antenna
- 3 12V DC power connection
- 4 Coaxial cable(for TV receiver connection)
- 5 110V AC/12V DC Power adaptor

FR

- 1 Antenne VHF
- 2 Antenne UHF
- 3 Connecteur 12 V CC
- 4 Câble coaxial (pour la connexion au récepteur TV)
- 5 Adaptateur secteur 110 V CA/12 V CC

ES

- 1 Antenna VHF
- 2 Antenna UHF
- 3 Toma de alimentación 12V DC
- 4 Cable coaxial (para conectar el televisor)
- 5 Adaptador de alimentación de 110V CA/12 V CC

Always there to help you

SDV1226/27

Enjoy your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)




EN User manual

FR Mode d'emploi

ES Manual del usuario

# PHILIPS



EN

- 1 Connect one end of your coaxial cable to the signal output of the antenna.
- 2 Connect the other end to the input on the TV receiver.
- 3 Connect the DC plug to the antenna and the power supply to a 110V AC outlet.(Fig.1)

FR

- 1 Branchez une extrémité du câble coaxial sur la sortie du signal de l'antenne.
- 2 Branchez l'autre extrémité sur l'entrée du récepteur TV.
- 3 Branchez la fiche CC sur l'antenne et l'alimentation sur une prise 110V CA.(Fig.1)

ES

- 1 Conecte uno de los extremos del cable coaxial a la salida de señal de la antena.
- 2 Conecte el otro extremo a la entrada del receptor de televisión.
- 3 Conecte la toma DC a la antena y la fuente de alimentación a una toma de CA de 110V.(Fig.1)