



Philips  
CD Soundmachine

Compact design  
USB

AZ318B

## Enjoy music wherever you go

Want to enjoy the music collections stored on a portable music player without using headphones? Plug the USB Direct socket into the Philips CD soundmachine and enjoy your favourite digital music through the powerful speakers — anytime, anywhere.

### **The ultimate listening experience**

- USB Direct for easy MP3 music playback
- Play MP3-CD, CD and CD-R/RW
- FM digital tuning

### **Easy to use**

- Audio-in for easy portable music playback
- 20 preset tuning stations
- CD repeat/shuffle/Programme for personalised music enjoyment

### **Rich and clear sound**

- Dynamic Bass Boost for deep and dramatic sound

# PHILIPS

# Specifications

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/reverse, next/previous album search, next/previous track search, repeat/shuffle/programme
- USB playback mode: fast forward/reverse, next/previous album search, next/previous track search, repeat/shuffle/programme

## Tuner/Reception/Transmission

- Tuner bands: FM
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning

## Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: up/down
- Maximum output power (RMS): 3 W

## Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

## Connectivity

- USB: USB host
- Audio in (3.5 mm)

## Convenience

- Display type: LCD display
- Loader type: top

## Power

- Power type: AC Input
- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6

## Accessories

- Cables/Connection: power cord
- Others: User Manual
- Warranty: Warranty leaflet

## Dimensions

- Gross weight: 1.62 kg
- Packaging width: 280 mm
- Packaging height: 260 mm
- Packaging depth: 156 mm
- Weight: 1.1 kg
- Main unit depth: 232 mm
- Main unit height: 124 mm
- Main unit width: 252 mm



# Highlights

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## CD repeat/shuffle/Programme

CD repeat/shuffle/Programme for personalised music enjoyment

## Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3)". .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.



Issue date 2019-11-20

Version: 4.0.11

12 NC: 8670 001 31204  
EAN: 69 51613 99214 2

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)