

## SPA1310

Instructions for use **English**  
 Bedienungsanleitung **Deutsch**  
 Instructions pour l'utilisation **Français**  
 Istruzioni per l'uso **Italiano**  
 Gebruiksaanwijzing **Nederlands**  
 Pokyny k použití **Čeština**  
 Vejledning **Dansk**  
 Instruktionerna för använda **Svensk**  
 Modo de empleo **Español**  
 Käyttöohje **Suomi**  
 Οδηγίες Χρήσης **Ελληνικά**


Használati utasítás **Magyar**  
 Bruksanvisning **Norsk**  
 Instruções de uso **Português**  
 Instrukcja użytkowania **Polski**  
 Bruksanvisning **Svenska**  
 Kullanma talimatı **Türkçe**  
 사용 설명 **한국어**  
 Чказания по применению **Русский**  
 使用説明書 **中文**  
 使用说明书 **中文**



# PHILIPS



### Important notes for United Kingdom only



#### Caution:

- The product shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the product.
- To be completely disconnect the power input, the mains plug of the product shall be disconnected from the mains.
- The mains plug of the product should not be obstructed OR should be easily accessed during intended use.