




# Quick Start Guide




Main unit




1 x MP3 link cable



Remote Control



2 x Loudspeaker boxes





User Manual




Quick Start Guide


# A Connect





# B Set clock





# C Play discs



## D Listen to radio



## E Play iPod



## 28 day no quibble refund

If you're not delighted by your product, simply bring it back within 28 days for a no quibble refund. Don't forget to include all of the item's original components (for example remote control or power cable) and packaging along with your receipt or other proof of purchase.

## FREE 1 year guarantee

All our electrical items are covered by a full 1 year ASDA guarantee from the day you buy it. In the unlikely event that your product is faulty, don't worry, here's what you should do

- 1 First call our Customer Helpline first as they may be able to help you with the problem.
- 2 If the problem can't be resolved, you will receive a reference number.
- 3 Take the reference number along with the item, all its components and your receipt to your nearest store for a full refund.  
This does not affect your statutory rights.

Customer Helpline  
**0845 300 7775**

Monday – Friday 9am – 8pm, Saturday 9am – 5pm,  
Sunday 11am – 4pm. Calls charged at local rates.



© 2009 Koninklijke Philips Electronics N.V.  
All rights reserved.

