





118/173


United Arab Emi..


United Kingdom


United States - ...

United States - ...













Wireless (WiFi)

Wired (Ethernet)

Enter Key

leys are case-sensitive. Use key <a/A





Push button (WPS...

Pin entry (WPS - PIN)

Acquiring IP address..

Press <Back> to enter

IP address manually




Network A

Network B

Network C

Network D





















































Management OK Count





All songs

Playlists




Doris Kokis / 你好

Love willツ한繁中...



App Store





Philips MyRemote





