



Philips
CD Soundmachine with
Dynamic Bass Boost

MP3
cassette

AZ1032

all-in-one, MP3 music with enriched bass

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1032 lets you indulge in the pleasures of enjoying your favorite music in enriched bass sound with the help of easy-to-use functions.

Feature-packed CD player

- MP3-CD, CD-R/RW compatible
- CD Shuffle/Repeat for personalized music enjoyment

Enhanced bass performance

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- 10.2 cm (4") full range speakers for powerful sound

Easy to use

- CD to tape synchro-start recording
- Multi-functional LCD display
- Stereo headphone socket

PHILIPS

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- Number of decks: 1
- Cassette Deck Technology: Mechanical

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

Sound

- Output power (RMS): 2X1.2W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: rotary

Convenience

- Display Type: LCD



Connectivity

- Headphone: 3.5 mm

Power

- Mains power
- Battery type: LR14
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate
- Remote control

Dimensions

- Packaging dimensions (W x H x D): 335 x 195 x 272 mm
- Product dimensions (W x H x D): 290 x 150 x 212 mm
- Weight: 2.2 kg
- Weight incl. Packaging: 2.8 kg

Highlights

MP3-CD, CD-R/RW compatible

MP3-CD, CD-R/RW compatible

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

10.2 cm/4" full range speakers

10.2 cm (4") full range speakers for powerful sound

CD synchro-start recording

CD to tape synchro-start recording

Multi-functional LCD display

Multi-functional LCD display

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.



Issue date 2014-02-05

Version: 1.0.3

12 NC: 9073 101 02255
EAN: 87 10895 92318 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com