

Philips CD Soundmachine with Dynamic Bass Boost

AZ1047

Enjoy music from multisources wherever you go

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1047 lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

The ultimate listening experience

- Play MP3-CD, CD and CD-R/RW
- Autostop cassette deck
- FM/MW tuner for radio enjoyment

Easy to use

- MP3 Link for portable music playback
- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

Rich and clear sound

• Dynamic Bass Boost for deep and dramatic sound



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- · Loader Type: Top
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle
- Programmable Tracks: 20
- · Number of decks: 1
- · Cassette Deck Technology: Mechanical

Tuner/Reception/Transmission

• Tuner Bands: FM, MW · Antenna: FM Antenna

Sound

- Output power (RMS): 2 X 1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- · Speaker diameter: 3.5"
- Volume Control: rotary

Audio Recording

- Tape Recording Enhancement: CD Synchro Start Recording
- Recording Media: Tape







Convenience

• Display Type: LCD

Connectivity

• 3.5mm stereo line in: (MP3 LINK)

Power

- · Battery type: LR14 Battery voltage: 1.5 V
- Number of batteries: 6
- Mains power: 110 127V, 220 240V selectable

• Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 320 x 275 x 175 mm
- Product dimensions (W x H x D): 292 x 142 x 243 mm
- Weight: 2 kg
- · Weight incl. Packaging: 2.4 kg

Highlights

Play MP3-CD, CD and CD-R/RW MP3 stands for "MPEG 1 Audio layer-7.6 cm (3") .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Autostop cassette deck

Autostop cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2012-07-31

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 55877 EAN: 87 12581 50252 2

www.philips.com