

Philips
Micro Hi-Fi System

MP3/WMA-CD playback

USB Direct

MCM128B



Compact Micro with USB Direct

Compact and stylish design packs a powerful punch. Combining superb performance and essential functionalities without compromising on aesthetics, just sit back and enjoy music the way you like it.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB devices

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 15 W RMS/2 x 30 W music power

Wake up to CD or radio tunes

- Wake-Up and Sleep Timer
- Stereo tuning with digital readout

Fits any space, any lifestyle

- Compact design

PHILIPS
sense and simplicity

Specifications

Sound

- Output Power: 2 x 15 watts RMS/2 x 30 watts music power
- Sound Enhancement: Digital Sound Control, Dynamic Bass Boost
- Volume Control: Volume Control up/down

Loudspeakers

- Main Speaker: 3.5" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Play/Pause, Stop, Fast Reverse/Fast Forward, Previous/Next, Programme Play, Repeat, Shuffle

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

Connectivity

- Headphones: 3.5 mm

- Other connections: FM fixed pigtail antenna, MW Antenna
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight colour: White
- Eco Power Standby: 1 watt

Accessories

- Remote control: 20-key with battery
- Included Accessories: FM/MW Antenna, Guarantee booklet, Quick Use Guide
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 150 x 150 x 244 mm
- Main speaker dimensions (W x H x D): 150 x 150 x 200 mm
- Packaging dimensions (W x H x D): 200 x 535 x 302 mm
- Weight incl. Packaging: 5.583 kg



Highlights

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2009-07-17

Version: 2.0.4

12 NC: 8670 000 29701
EAN: 87 12581 33296 9

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com