

Philips CD Soundmachine
CD
A71123B

Music on the move

Compact and stylish, this all-in-one player plays all CDs including CD-R and CD-RW. Sit back and enjoy music convenience with its programmable 20 track replay.

Enjoy your music from different sources

- CD player
- Compatible with CD-Recordable and CD-ReWritable
- FM/MW tuner for radio enjoyment

Easy to use

- CD shuffle/program/repeat for personalized music enjoyment
- Multi-functional LCD display
- Stereo headphone socket



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Programmable Tracks: 20
- Tracks: 20

Tuner/Reception/Transmission

- Antenna: FM Antenna
- Tuner Bands: FM, AM

Sound

- Output power (RMS): 2x1W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Convenience

- Display Type: LCD
- Display Digits: 2



Connectivity

• Headphone: 3.5 mm

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Accessories

• Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D):
- 397 x 169 x 246 mm
- Product dimensions (W x H x D):
- 350 x 127 x 217 mm
- Weight: 1.9 kg
- Weight incl. Packaging: 2.55 kg

AZ1123B/37

Highlights

CD player CD player

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW tuner

FM/MW (AM) stereo tuner

CD shuffle/program/repeat

The "Shuffle/Program/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle", "Program" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Multi-functional LCD display

Multi-functional LCD display

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.



Issue date 2011-06-22

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 1.1.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

12 NC: 8670 000 31244 UPC: 6 09585 13543 7

www.philips.com