

Philips
CD Soundmachine

Lifestyle design
MP3-CD

AZ1133



Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The sleek and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favorite MP3 music with the help of easy-to-use functions.

Everything you need

- Play MP3-CD, CD and CD-R/RW
- FM/MW tuner for radio enjoyment

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- Stereo headphone jack for better personal music enjoyment

PHILIPS

Specifications

Audio playback

- Playback media: MP3-CD, CD, CD-R, CD-RW
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program

Tuner/Reception/Transmission

- Antenna: FM antenna
- Tuner bands: FM, MW

Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

Convenience

- Display type: LCD display
- Display Digits: 3
- Loader type: top

Connectivity

- Audio/Video output: Headphone (3.5mm)

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input

Accessories

- Cables/Connection: power cord
- Others: User Manual
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 2.55 kg
- Packaging depth: 246 mm
- Packaging height: 169 mm
- Packaging width: 397 mm
- Weight: 1.9 kg
- Main unit depth: 217 mm
- Main unit height: 127 mm
- Main unit width: 350 mm




Highlights

Play MP3-CD, CD and CD-R/RW




MP3 stands for "MPEG 1 Audio layer-7.6 cm (3")". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

FM/MW tuner



FM/MW (AM) stereo tuner

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Stereo headphone jack

Connect your own headphones with this Philips device for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to this device.



Issue date 2015-01-22

Version: 1.0.4

12 NC: 8670 000 39085
EAN: 87 12581 41286 9

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com