

Philips
CD Soundmachine with
Dynamic Bass Boost

AZ1022

# Program your favorite music

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1022 lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

## Enjoy favorite music from three different sources

- · CD player
- FM/MW stereo tuner
- Stereo cassette deck

#### Rich and clear sound experience

• Dynamic Bass Boost for deep and dramatic sound

## Easy to use

- CD shuffle/program/repeat
- Multi-functional LCD display
- Stereo headphone socket



## Specifications

#### **Audio Playback**

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Number of decks: 1
- · Cassette Deck Technology: Mechanical
- Programmable Tracks: 20

## Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

#### Sound

- Output power (RMS): 2X1.0W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3.5"
- Volume Control: rotary

#### **Audio Recording**

- Tape Recording Enhancement: CD Synchro Start Recording
- Recording Media: Tape





#### **Convenience**

• Display Type: LCD

#### **Connectivity**

• Headphone: 3.5 mm

#### **Power**

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

#### **Accessories**

 Included Accessories: AC Power Cord, User Manual, Warranty certificate

#### **Dimensions**

- Packaging dimensions (W x H x D): 325 x 180 x 280 mm
- Product dimensions (W x H x D): 290 x 143 x 240 mm
- Weight: 1.99 kg
- Weight incl. Packaging: 2.64 kg
- Product weight: 1.99 kg

## Highlights

#### **CD player** CD player

o\_ p.u/o.

## FM/MW stereo tuner

FM/MW stereo tuner

## Stereo cassette deck

Stereo cassette deck

#### **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## CD shuffle/program/repeat

CD shuffle/program/repeat

#### Multi-functional LCD display Multi-functional LCD display

## Stereo headphone socket

Stereo headphone socket



Issue date 2015-01-22

Version: 3.1.10

Al

© 2015 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 101 02343 EAN: 87 10895 93240 0

www.philips.com