

# Quick start guide



## Check your iOS version 检查 iOS 版本



## Check your home router 检查家庭路由器

Does your router have a WPS button?  
路由器是否具有 WPS 按钮?

**No**

No, for router without WPS button (or not sure), go to option 1.  
Yes, for router with WPS button, go to option 2.

否, 对于没有 WPS 按钮 (或不确定的) 的路由器, 请转到选项 1。  
是, 对于具有 WPS 按钮的路由器, 请转到选项 2。

## Option 1: Set up using iPod Touch / iPhone / iPad

选项 1: 使用 iPod Touch/iPhone/iPad 进行设置

- Connect power. 连接电源。  
Wait for 35 seconds until the green light blinks slower. 等待 35 秒钟, 直至绿色指示灯闪烁变慢。
- Press and hold **Wi-Fi SETUP** for 5 seconds, then the light alternates between green and yellow. 按住 **Wi-Fi SETUP** 5 秒钟, 然后指示灯将以绿色和黄色交替闪烁。
- Open Settings. 打开设置。
- Tap **Wi-Fi**. 轻击 **Wi-Fi**.
- Wait up to 30 seconds until "Philips Fidelio AirPlay" is detected. Then, tap it. 等待 30 秒钟, 直至检测到 "Philips Fidelio AirPlay", 然后轻击它。
- Settings → General → Network. 禁用 3G 网络。  
Remember to turn on the 3G network after successful AirPlay connection. 在 AirPlay 连接成功后, 请记得打开 3G 网络。
- Open Safari. 打开 Safari。
- Enter the IP address 192.168.1.1. 输入 IP 地址: 192.168.1.1.
- Follow the on-screen instructions to configure the Wi-Fi settings for the device. 按照屏幕上的说明为设备配置 Wi-Fi 设置。
- Wait up to 2 minutes until the light stops flashing and you hear a confirmation tone. 等待 2 分钟, 直至指示灯停止闪烁, 此时您将听到一声确认声。

## Option 2: Set up using WPS

选项 2: 使用 WPS 进行设置

- Connect power. 连接电源。  
Wait for 35 seconds until the green light blinks slower. 等待 35 秒钟, 直至绿色指示灯闪烁变慢。
- Press the **WPS** button on your router. 按路由器上的 **WPS** 按钮。
- Press **Wi-Fi SETUP** once, then the light alternates between red, green and yellow. 按一下 **Wi-Fi SETUP**, 然后指示灯以红色、绿色和黄色交替闪烁。
- Wait up to 2 minutes until the light stops flashing and you hear a confirmation tone. 等待 2 分钟, 直至指示灯停止闪烁, 此时您将听到一声确认声。

## Start to enjoy your AirPlay 开始享受 AirPlay

- Open Settings. 打开设置。
- Check your router is selected. 检查是否选择了路由器。
- Open iPod application. 打开 iPod 应用程序。
- Tap AirPlay icon. 轻击 AirPlay 图标。
- Select your device. 选择设备。
- Tap ▶ to play music. 轻击 ▶ 播放音乐。

If the AirPlay icon does not appear or there is no sound output, try the following ways:  
 ① Turn on and off the Airplane Mode in Settings.  
 ② Restart your iPhone.  
 ③ It is recommended to restart your home router.  
 如果 AirPlay 图标没有出现或没有声音输出, 请尝试以下方法:  
 ① 在“设置”中打开和关闭“飞行模式”。  
 ② 重启 iPhone。  
 ③ 建议您重启家庭路由器。

