











- Quick start guide **English**  
 Lynvejledning **Dansk**  
 Schnellstartanleitung **Deutsch**  
 Guía de configuración rápida **Español**  
 Guide de démarrage rapide **Français**  
 Guida di avvio rapido **Italiano**  
 Snelstartgids **Nederlands**  
 Snabbstartguide **Svenska**  
 Stručný návod k rychlému použití **Čeština**  
 快速启用指南 **简体中文**
- Οδηγός γρήγορης έναρξης **Ελληνικά**  
 Pikaopas **Suomi**  
 Rövid üzembe helyezési útmutató **Magyar**  
 Skrócona instrukcja obsługi **Polski**  
 Manual de Início Rápido **Português**  
 Краткое руководство **Русский**  
 Stručná úvodná príručka **Slovensky**  
 快速启用指南 **繁體中文**

**PHILIPS**



[www.philips.com/support](http://www.philips.com/support)



- iPod touch (1G, 2G, 3G, 4G)
 iPhone, iPhone 3G, iPhone 3GS
 iPhone 4
- iPod nano 1G
 iPod nano 2G
 iPod nano 3G
 iPod nano 4G
 iPod nano 5G
 iPod nano 6G
- iPod mini
 iPod classic
- iPod with video
 iPod with color display
- 