






Register your product and get support at
www.philips.com/welcome

HTS3220




Quick Start




PHILIPS



Power Cord



Video cable








SCART Adapter






FM Antenna

1







2

1

SOURCE

TV

AV

HTS

2

3

HOME THEATER

5

6

HOME THEATER

General Setup

Easylink Setup


- Disc Lock
- Display Dim
- OSD Language
- Screen Saver
- Sleep Timer
- DivX(R) VOD Code

General Setup


- Easylink Setup
- Disc Lock
- Display Dim
- OSD Language**
 - Auto
 - English**
 - Français
 - Deutsch
 - Italiano
 - Español
 - Português
 - Nederlands
- Screen Saver
- Sleep Timer
- DivX(R) VOD Code





3

DISC



FM





Specifications are subject to change without notice
 Trademarks are the property of Koninklijke Philips Electronics N.V.
 or their respective owners
 2010 © Koninklijke Philips Electronics N.V. All rights reserved.
 sgythy_1026/12_v3

Be responsible
 Respect copyrights

