
## Always there to help you

Register your product and get support at www.philips.com/welcome



SPA20



## User manual



## Contents

1	Important Important safety instructions	<b>3</b>
2	Notice Disposal of your old product	<b>4</b>
3	Your multimedia speaker	5
4	Installation	6
5	Product information Specifications	<b>7</b>
6	Troubleshooting	8

## 1 Important

#### Important safety instructions

- Read and follow all these instructions.
- The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.
- No naked flame sources, such as lighted candles, shall be placed on the products.
- Keep this product away from direct sunlight, naked flames or other heat sources.
- Only use attachments/accessories specified by the manufacturer:



#### Warning

- · Never remove the casing of this product.
- Never place this product on other electrical equipment.

### Notice

Any changes or modifications made to this device that are not expressly approved by WOOX Innovations may void the user's authority to operate the equipment.

#### Disposal of your old product



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/ EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste.

Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

#### **Environmental information**

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.) Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of



equipment.

· The type plate is located on the bottom of the product.

packaging materials, exhausted batteries and old

# 3 Your multimedia speaker


Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

If you contact Philips, you will be asked for the model and serial number of this product. The model number and serial number are on the bottom of the product. Write the numbers here:

Model No.		
Serial No		

## 4 Installation



- 1 Insert the USB plug into the USB socket of your PC.
- 2 Insert the audio input plug into the headphone jack of your PC.
- 3 Adjust the volume of your PC.
- 4 After use, disconnect the USB and audio input plugs.

## 5 Product information



 Product information is subject to change without prior notice.

### **Specifications**

USB Power Input	5V === 500mA		
Dimensions			
- Main Unit $(W \times H \times D)$	$80 \times 122 \times 73$ mm		
Weight			
- Main Unit	0.6kg		

#### System Requirements:

PC	Mac
Windows® 98SE, Windows® ME,	Mac OS9/
Windows® 2000, Windows® XP, or	$OS^{\mathbb{R}} X$ , or
Windows® Vista™, Windows 7	later

## 6 Troubleshooting

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using the product, check the following points before requesting service. If the problem remains unsolved, register your product and get support at www.philips.com/support.

#### No sound

- Make sure that the speakers are correctly installed.
- Adjust the volume of your PC.



Specifications are subject to change without notice 2013 ©WOOX Innovations Limited.All rights reserved. Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by WOOX Innovations Limited under license from Koninklijke Philips N.V.

