


A Connect 연결 連接



EN

Note:

You can set the clock in the standby mode only.

- 1 Press and hold **PROG/CLOCK SET** to enter the clock setting mode.
↳ **[SET CLOCK]** (set clock) scrolls on the screen.
- 2 Press **◀◀▶▶** repeatedly to select 12 hour or 24 hour format.
- 3 Press **PROG/CLOCK SET** to confirm.
↳ The hour digits are displayed and begin to blink.
- 4 Press **◀◀▶▶** to set the hour.
- 5 Press **PROG/CLOCK SET** to confirm.
↳ The minute digits are displayed and begin to blink.
- 6 Press **◀◀▶▶** to set the minute.
- 7 Press **PROG/CLOCK SET** to confirm the clock setting.


KO

참고:

시계는 대기 모드에서만 설정할 수 있습니다.

- 1 **PROG/CLOCK SET**을 누른 채로 기다려 시계 설정 모드를 활성화합니다.
↳ **[SET CLOCK]**(시계 설정)이 화면에 나타납니다.
- 2 **◀◀▶▶**을 여러 번 눌러 눌러 12시간 형식 또는 24시간 형식을 선택합니다.

B Set clock 시계 설정 設定時鐘



- 3 **PROG/CLOCK SET**을 눌러 확인합니다.
↳ 시를 나타내는 숫자가 표시되어 깜박이기 시작합니다.
- 4 **◀◀▶▶**을 눌러 시간을 설정합니다.
- 5 **PROG/CLOCK SET**을 눌러 확인합니다.
↳ 분을 나타내는 숫자가 표시되어 깜박이기 시작합니다.
- 6 **◀◀▶▶**을 눌러 분을 설정합니다.
- 7 **PROG/CLOCK SET**을 눌러 시계 설정을 확인합니다.


ZH-TW

備註：


僅能在待機模式下設定時鐘。

- 1 按住 **PROG/CLOCK SET** 進入時鐘設定模式。
↳ 畫面顯示 **[SET CLOCK]**(設定時鐘) 滾輪。
- 2 重複按 **◀◀▶▶** 選擇 12 小時或 24 小時制。
- 3 按 **PROG/CLOCK SET** 確認。
↳ 小時數字會顯示並開始閃爍。
- 4 按 **◀◀▶▶** 設定小時。
- 5 按 **PROG/CLOCK SET** 確認。
↳ 分鐘數字會顯示並開始閃爍。
- 6 按 **◀◀▶▶** 設定分鐘。
- 7 按 **PROG/CLOCK SET** 確認時鐘設定。


C Play a disc
디스크 재생
播放光碟



D Listen to radio
라디오 청취
收聽收音機



E Play from USB
USB에서 재생
播放 USB 裝置



F Play iPod/iPhone
iPod/iPhone 재생
播放 iPod/iPhone

