



Philips
Universal remote control

Universal

SRU4040

Flips open and close

for compact convenience

Feature-packed 4-function remote control flips open and close for the ultimate in sleek, stylish convenience. Controls up to 4 components with advanced DVD and satellite functionality. Includes two CR2032 batteries.

Enjoy control of your components open or closed

- Shortcut keys
- Full 4 device design
- Advanced Satellite and DVD functions

PHILIPS
sense and simplicity

Specifications

Inner Carton

- EAN/UPC/GTIN: 1 06 09585 12100 0
- Gross weight: .78 kg
- Height: 120 mm
- Length: 285 mm
- Quantity: 4
- Width: 110 mm

Outer Carton

- EAN/UPC/GTIN: 2 06 09585 12100 7
- Gross weight: 3.4 kg
- Height: 150 mm
- Length: 345 mm
- Quantity: 12
- Width: 300 mm

Packaging Data

- EAN/UPC/GTIN: 6 09585 12100 3
- Gross weight: .17 kg
- Height: 35 mm
- Length: 275 mm
- Width: 110 mm

Power

- Battery type: CR2032
- Batteries included
- Battery saving manager: Auto switch on/off
- Number of batteries: 2

Highlights

Shortcut keys

Basic control keys on the front of the remote simplify use. Open to choose component, then close to access basic functions.

Full 4 device design

Enjoy remote access to your TV, VCR, DVD player, cable or satellite systems with the remote fully open. Choose one, then close the remote for basic function access to that component.

Advanced functions

Advanced functions allow you to replace your original remotes without loss of control. DVD functions include chapter+/-, scan +/-, and menu. Satellite functions include guide, menu, info, select/ok and exit



Issue date 2011-01-09

Version: 2.0.5

12 NC: 8670 000 24882
UPC: 6 09585 12100 3

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com